

TRACTORS POWER STEERING CONVERSION KIT WITH BY-PASS SYSTEM INSTALLING INSTRUCTION

SAME

HYDRAULIC STEERING CONVERSION KITS WITH BY-PASS SYSTEM AND SECURITY VALVE FOR SAME 70-80 TRACTORS ASSEMBLING INSTRUCTION

1. Assemble hydraulic oil pump.
2. Assemble oil reservoir.
3. Mount lift assembly bracked.
4. Assemble valve and piston.
5. 5/8 R6 hose from reservoir to oil pump.
6. Pressure hose 5/6 R1 from oil pump to lift .
7. Return hose 3/8 R6 from lift to reservoir.
8. The long rod will be installed.
9. After mounting use special sae 10 or 20 to start the engine and check the level add some more if necessary.
10. The adjusting screw of the pressure valve.

